






Power On		Red Light
Power Off		No Light
Low Battery		Flashing Red
Charging with Computer		Alternative Flashing Green & Red - CAN NOT RECORD WHILE CHARGING
Charging with Wall Outlet		Alternative Flashing Green & Red - CAN RECORD & CHARGE AT SAME TIME
Fully Charged		No Light
No SD Card		Flashing green 8 times
Photo Mode		Green Light
Picture Function		Flashes Green Once When Photo is Taken